



## V6 & V8 Interior Gauge Pack Cluster Trim

### Installation Instructions



Congratulations! On your purchase of the V6 & V8 Interior Gauge Pack Cluster Trim we, know that you will enjoy having this great product in your Camaro.

Time needed for this job is about 15-20mins. Please completely read these instructions prior to beginning. It will only take you a few minutes to read. Do not skip any of the steps.

**Step One:** Trial fit the V6 & V8 Interior gauge pack cluster trim before installing any peeling off the 3M automotive tape.



**Step Two:** Make sure that you clean the area where the V6 & V8 Interior gauge pack cluster trim is going to go with alcohol and let it dry and, then clean it again with alcohol. Make sure that it is completely dry before installing the V6 & V8 interior gauge pack cluster trim.

**Step Three:** Remove the 3M tape from the backside of the trim and carefully position it in place and firmly press into place. Repeat the process on the other 3 trim pieces.

**Step Four:** Congratulations! You are finish. Enjoy your V6 & V8 interior gauge pack cluster trim.

## **Cleaning Instructions**

To maintain the appearance, be sure to only use a polish suitable for mirrored stainless steel and only apply polish with a 100% microfiber cloth or shammy. Remember, mirrored stainless steel scratches easily. If you have one of the color powder coated ones it does not have a clear coat like you would have on your Camaro and it will also scratch easily so, be sure to be careful when cleaning it.

**Note:** This product will come with protecting vinyl just simply pull off the protective vinyl to expose the beautiful mirrored finish. There may be some residue from where the laser cut through the vinyl which you can remove with 100% alcohol and a cotton pad. If you have one of our color powder coated ones it will not come with a protecting vinyl.

