



V6 & V8 Trunk Trim Cover Installation Instructions



Congratulations! On your purchase of the V6 & V8 Trunk Trim Cover we know that you will enjoy having this great product in your Camaro.

Time needed for this job is about 15-20 mins. Please completely read these instructions prior to beginning. It will only take you a few minutes to read. Do not skip any of the steps.

Step One: To install your trunk trim cover leave the vinyl coating on while you are installing the trunk trim cover so, you don't scratch it or get finger prints on it.

Step Two: Trial fit the trunk trim cover before removing the adhesive. It will fit tight around the bowtie and there is not much wiggle room. We rolled the trunk trim cover so, it would curve the shape of your trunk but, since we mailed it flat card board you might have to form it again to your trunk by bending it a bit.



Step Three: Make sure that you clean your area where the trunk trim cover is going to go with alcohol and let it dry and, then clean it again with alcohol. Make sure that it is completely dry before installing the trunk trim cover.

Step Four: We added adhesive tape on the back to the truck trim panel and when you are ready peel off the adhesive tape.

Step Five: Make sure that you applied pressure on all of the trunk trim cover for about 1 to 2 mins to make sure it stays in place.

Step Six: Start in the middle where the bowtie is and working your way out on both sides of the bowtie removing the adhesive tape as you are applying the trunk trim cover. Make sure that you aligning it top and bottom as you go. Once you stick it on your truck you will not be able to remove it without damaging the trunk trim cover.

Step Seven: After you install the trunk trim cover then, remove the vinyl coating to expose the mirrored finish.

Step Eight: Congratulations! You are finish. Enjoy your new stainless steel mirrored trunk trim cover.

Cleaning Instructions

To maintain the appearance, be sure to only use a polish suitable for mirrored stainless steel and only apply polish with a 100% microfiber cloth or shammy. Remember, mirrored stainless steel scratches easily. So be sure to be careful when cleaning it.

Note: There may be some lines on the underside from handling and, making it which you will not see once you install it in your Camaro. This product will come with protecting vinyl just simply pull off the protective vinyl to expose the beautiful mirrored finish. There may be some residue from where the laser cut through the vinyl which you can remove with 100% alcohol and a cotton pad.

