



## V6 & V8 Underhood ABS Brake Distribution Block Cover Installation Instructions



Congratulations! On your purchase of the V6 & V8 ABS distribution cover we, know that you will enjoy having this great product in your Camaro.

Time needed for this job is about 5 mins, you will not need any tools with you at the car. If it takes you longer do not worry. Take your time, and work at a comfortable pace. Please completely read these instructions prior to beginning. It will only take you a few minutes to read. Do not skip any of the steps.

**CAUTION:** Stainless is very sharp and blood will stains the ABS Cover.

**Step One:** Make sure that the engine is off and cool.

**Step Two:** Trial fit the cover prior to affixing it permanently.

**Step Three:** Once you are sure of its placement, take note of where the areas comes in contact with the each other.

**Step Four:** Clean and dry all surfaces very well especially where the tape will come in contact with the cover, we recommend using rubbing alcohol or some other type of similar cleaner.

**Step Five:** The tape section needs to be place in these areas in order to touch both surfaces.  
(Not Included)

**Step Six:** Remove the 3M tape.

**Step Seven:** Carefully position the cover in place, take you time because once the tape touches any surface, it's extremely hard to remove or reposition the cover.

**Step Eight:** Apply a good amount of pressure to the cover to assure good adhesion for about 2-3mins

**Step Nine:** Congratulations! You are finish. Enjoy your New ABS Brake Distribution Block Cover.

## **Cleaning Instructions**

To maintain the appearance, be sure to only use a polish suitable for mirrored stainless steel and only apply polish with a 100% microfiber cloth or shammy. Remember, mirrored stainless steel scratches easily. So be sure to be careful when cleaning it.



Note: There may be some lines on the underside from handling and, making it which you will not see once you install it in your Camaro. This product will come with protecting vinyl just simply pull off the protective vinyl to expose the beautiful mirrored finish. There may be some residue from where the laser cut through the vinyl which you can remove with 100% alcohol and a cotton pad.

